Module 2: Installation and Maintenance of Hardware and Its

Section 1 : Multiple Choice

- 1. Which of the following precautions should be taken before working on computer hardware?
 - a) Ensure the computer is plugged in to prevent electrostatic discharge.
 - b) Wear an anti-static wrist strap to prevent damage from electrostatic discharge.
 - c) Work on carpeted surfaces to prevent slipping.
 - d) Use magnetic tools to handle components more easily.

Ans: b) Wear an anti-static wrist strap to prevent damage from electrostatic discharge.

- 2. What is the purpose of thermal paste during CPU installation?
- a) To insulate the CPU from heat.
- b) To provide mechanical support for the CPU.
- c) To improve thermal conductivity between the CPU and the heat sink.
- d) To prevent the CPU from overheating.

Ans: c) To improve thermal conductivity between the CPU and the heat sink.

- 3. Which tool is used to measure the output voltage of a power supply unit (PSU)?
- a) Multimeter
- b) Screwdriver
- c) Pliers
- d) Hex key

Ans: a) Multimeter

- 4. Which component is responsible for storing BIOS settings, such as date and time, even when the computer is powered off?
 - a) CMOS battery
 - b) CPU
 - c) RAM
 - d) Hard drive

Ans: a) CMOS battery

Section 2 : True Or False

5. True or False: When installing a new hard drive, it is essential to format it before use.

Ans: True

6. True or False: A POST (Power-On Self-Test) error indicates a problem with the CPU.

Ans: False

7. True or False: It is safe to remove a USB flash drive from a computer without ejecting it first.

Ans: False

Section 3: Short Answer

8. Describe the steps involved in installing a new graphics card in a desktop computer.

Ans:

- Power off the computer and unplug all cables.
- Open the side panel of the case.
- Ground yourself to prevent static damage.
- Locate the PCIe x16 slot on the motherboard.
- Remove the case expansion slot cover(s).
- Insert the graphics card firmly into the PCIe slot.
- Secure the card with screws or the locking bracket.
- Connect PCIe power cables from the PSU if required.
- Close the case, reconnect cables, and power on.
- Install/update the latest GPU drivers.

9. What is RAID, and what are some common RAID configurations?

Ans:

• RAID (Redundant Array of Independent/Inexpensive Disks) is a method of combining multiple hard drives to improve performance, reliability, or both.

Common RAID configurations:

- RAID 0 (Striping): Data split across drives → Faster performance, no redundancy.
- **RAID 1 (Mirroring):** Data duplicated on two drives → High reliability, reduced storage capacity.
- RAID 5 (Striping with Parity): Data and parity spread across 3+ drives → Balance of performance and redundancy.

RAID 10 (1+0): Combines mirroring and striping \rightarrow High performance and redundancy, requires at least 4 drives.


Section 4: Practical Application

10. Demonstrate how to replace a CPU fan in a desktop computer.

CPU Fan Replacement

A) Replace just the CPU fan

- Shut down & unplug pc.
- Open the side panel, place case on a strale, non-carpert
- Ground yourself, wear an anti-static wrist strap or touch bare metal on case
- Locate CPU cooler
- Some airflow direction on the second on the second or t the old fan arror to yehrs:
- Unplug the fan from motherboad header
- Remove the fan Unclip metel clips or unscrewa











- Mount the new fam to heatsink wcsancam/mear call scors
- Plug the fan back into CPU_FAN header
- 10 Cable-manage to reconnect power, boot


B) Replace the entire cooler

- Shut down & unplug pc.
- Open the side panel, oird groose case on a stable, non-carpet
- 6 Unplug ean tor ince hearbard header
- Remove the ian conter or ins
- 8 Inel/AMD screw mounts: for hine int loasen a cew t-anpio wenll free
- Plug the fan back into CPU_FAN
- 10 Cable-manage to ensure
- Blades won't hit wires fit n aminc
- Close the case, reconnect power

- Clean old paste from cpu and cooler base with alcohol and lint-free
- 8 Loosen new paste to CPU
- Pea-sized dot (or a narrown line in long, reclangu
- install the new cooler, absning posts/hor les and lowering straight down
- Attach the new cooler, atigning posts/holes and lowering straight b
- Tighten evenly in a cross pattern until snug and locking intel push-pins if
- Plug fan into the CPU_FAN header and tidy-c









Section 5: Essay

11. Discuss the importance of regular maintenance for computer hardware and provide examples of maintenance tasks.

Ans: Regular maintenance of computer hardware is essential to ensure smooth performance, extend the lifespan of components, and prevent costly repairs. Over time, dust, heat, wear-and-tear, and improper usage can negatively affect hardware efficiency. By performing routine maintenance, users can keep their systems reliable and stable.

Importance of Regular Maintenance:

- 1. **Improves Performance** Keeps the system running smoothly without slowdowns or overheating.
- 2. **Prevents Hardware Failures** Reduces the risk of component damage (e.g., fans, hard drives).
- 3. **Extends Lifespan** Helps hardware last longer by minimizing stress and damage.
- 4. **Maintains Data Safety** Prevents sudden crashes that may lead to data loss.
- 5. **Cost-Effective** Saves money by avoiding early replacements or expensive repairs.

Examples of Maintenance Tasks:

• Cleaning Dust and Debris

Use compressed air or a soft brush to remove dust from fans, CPU coolers, and vents to prevent overheating.

• Checking and Replacing Thermal Paste

Replace old thermal paste on the CPU/GPU to maintain proper heat transfer.

• Monitoring Hard Drive Health

Use tools (e.g., CrystalDiskInfo) to check for bad sectors and back up important files regularly.

• Updating Software and Drivers

Keep BIOS, operating system, and drivers updated for better compatibility and security.

• Running Antivirus/Antimalware Scans

Protects the computer from threats that can corrupt hardware or slow performance.

• Cable Management

Organize internal and external cables to improve airflow and prevent accidental disconnections.

• Inspecting and Replacing Worn Components

Replace aging fans, faulty power supplies, or weak batteries (like the CMOS battery).